



1,4-Dioxane Formation, Control, and Occurrence in Cleaning Products

August 21, 2019

Outline

- Introduction
- Key Surfactant Classes
- Ethoxylation/Sulfation Processes
- Attributes of Ingredients
- 1,4-Dioxane in Ingredients
 - Formation
 - Control and Remediation
- Inventory of Cleaning Product Ingredients/Categories
- Measuring in Finished Products
- Environmental Monitoring 1,4-Dioxane
- Wrap-up



Quick Intro to ACI

- Founded in 1926, based in DC
- 140+ member companies
- Members include:
 - Manufacturers of household, I&I, healthcare cleaning products
 - Chemical producers (surfactants, fragrance, enzymes, etc.)
 - Finished packaging suppliers
 - Chemical distributors



american cleaning institute®
www.cleaninginstitute.org

A Snapshot of ACI Members





Surfactants

- Surfactants (surface active agents) are compounds that lower the surface tension (or interfacial tension) between two liquids, between a gas and a liquid, or between a liquid and a solid. Surfactants may act as detergents, wetting agents, emulsifiers, foaming agents, and dispersants.
- Vital role in modern society – keeping consumers, our homes, workplaces, and public places, clean and sanitary.
 - Without surfactants many essential products would not exist: examples: laundry detergent, surface cleaners (kitchen, bathroom etc.), dish soaps, oven cleaners, body washes, shampoo etc.





There are two key classes of ethoxylated surfactants

- Alcohol (Alkyl) Ethoxy Sulfate (ANIONIC SURFACTANT)



- Alcohol (Alkyl) Ethoxylate (NONIONIC SURFACTANT)




Ethoxylation and Sulfation



Ethoxylation

The process of reacting an alcohol with Ethylene Oxide to create an Ethoxylate/Alcohol Ethoxylate (non-ionic surfactant).



Where:

R = Carbon or Hydrogen (atom or molecule)


M⁺= Molecular ion

EO = Ethylene Oxide

AE= Alcohol Ethoxylate

SO_3 Sulfation of AE \longrightarrow AES

The process of reacting AE (nonionic surfactant) with Sulfur Trioxide to create an Alcohol (alkyl) Ethoxysulfate (anionic surfactant).



Where:

R = Carbon or Hydrogen (atom or molecule)

EO = Ethylene Oxide

AE = Alcohol Ethoxylate

AES = Alcohol Ethoxysulfate

SO_3 = Sulfur trioxide

Attributes Compared to Non-ethoxylated Surfactants

Alkyl Ethoxysulfates

- Mass efficiency
- Better cleaning
- Better hardness tolerance
- Good for cold water
- Better for solubility/compaction
- Lower solvent requirement
- Good for grass cleaning
- Good for sebum cleaning
- Enzyme Stability
- Very high foaming

Alkyl Ethoxylates

- Mass efficiency
- Better hardness tolerance
- Better for solubility/compaction
- No solvent requirement in several formulations
- Good for grass cleaning
- Good for sebum cleaning
- Low foaming
- Mildness
- Enzyme stability

Comparison of Cleaning Power Between Alcohol Ethoxylates or Methyl Ester Ethoxylates Having Different EO Chain Lengths and a Common Anionic Surfactant

Yu Nagai¹, Natsumi Togawa², Yumiko Tagawa³ and Keiko Gotoh²

Tenside Surf. Det. 51 (2014) 2 ^a

“Ethoxylated nonionic surfactant in laundry detergents is mostly biodegradable alcohol ethoxylates (AE), which can remove sebum efficiently at low temperature [3 – 6]. AE can maintain enzyme stability in the presence of anionic surfactant [7] and therefore has excellent compatibility with enzyme in laundry detergents. [8].”



Other references citing the attributes of ethoxylated surfactants

DETERGENTS

1. Hendrik Hellmuth and Michael Drejs

Understanding Interactions of Surfactants and Enzymes: Impact of Individual Surfactants on Stability and Wash Performance of Protease Enzyme in Detergents

J Surfact Deterg (2013) 16:115–121
DOI 10.1007/s12743-013-1371-y

ORIGINAL ARTICLE

Synergism and Performance Optimization in Liquid Detergents Containing Binary Mixtures of Anionic–Nonionic, and Anionic–Cationic Surfactants

Namita Jadhav · Babbar Adh · Farrokh B. Mallik

Received: 18 July 2011 / Accepted: 18 May 2012 / Published online: 24 June 2012
© AOCS 2012



Environmental Attributes of Ethoxylated Surfactants

- Rapid and ultimate biodegradation
- 83.5-99.8% removal in WWTP
- No adverse impacts on the aquatic or sediment environments

Critical Reviews in Environmental Science and Technology, 44:1893–1993, 2014
Published with license by Taylor & Francis
ISSN: 1064-3389 print / 1547-6537 online
DOI: 10.1080/10739149.2013.803777

Environmental Safety of the Use of Major Surfactant Classes in North America

CHRISTINA COWAN-ELLSBERRY,¹ SCOTT BELANGER,² PHILIP DORN,³ SCOTT DYER,² DREW MCAVOY,⁴ HANS SANDERSON,⁵ DONALD VERSTEEG,² DARCI FERRER,⁶ and KATHLEEN STANTON⁶

¹*CE² Consulting, LLC, Cincinnati, OH, USA*

²*The Procter & Gamble Company, Mason, OH, USA*

³*Shell Health Americas, Houston, TX, USA*

⁴*University of Cincinnati, Cincinnati, OH, USA*

⁵*Aarhus University, Roskilde, Denmark*

⁶*American Cleaning Institute, Washington, DC, USA*



Significance of Attributes of Ethoxylated (nonionic) and Sulfated (anionic) Ingredients

- Multiple performance benefits, formulation versatility
- Human and environmental safety profile
- Holistic sustainability benefits




Formation of 1,4-Dioxane

Why is 1,4-Dioxane found at low levels in AE and AES surfactants?

- 1,4-Dioxane is not intentionally added, or used as a raw material in production
- It is a trace level **technically unavoidable** byproduct (impurity) from the chemical reaction itself



Byproduct of Sulfation: 1,4-Dioxane



1,4-Dioxane can be formed from ethoxymers with >1 mole of EO when excess SO_3 is used.

Where:

SO_3 = Sulfur Trioxide

If $\frac{\text{mols } \text{SO}_3}{\text{mols feedstock}} > 1.04$ then rapid increase in 1,4-Dioxane (Foster, 1997)

Control/Remediation of 1,4-Dioxane in Cleaning Product Ingredients




Control of 1,4-Dioxane During Sulfation of AE AES

- Process and Equipment Factors
 - SO₃: AE feed mole ratio
 - Reactor Loading
 - Residence time of AES acid prior to neutralization
- Feedstock Composition Factors
 - Average degree of ethoxylation
 - PEG and moisture content
 - EO adduct distribution



Remediation Mechanism – Stripping AES Paste



Occurrence of Ethoxylated/Sulfated Ingredients in Cleaning Products

Inventory of Cleaning Product Ingredients/Categories

- 57 ethoxylated ingredients in cleaning products
- All product categories contain ethoxylated ingredients
 - All Purpose Cleaners
 - Dish Care Products
 - Laundry Care Products

Measuring 1,4-Dioxane in Finished Products

- DTSC proposed EPA methods 8260 and 8270 use Flame Ionization Detection (FID) which is not considered very sensitive
 - Methods will measure to 2 ppm in liquid products without extraction, and down to 0.02 ppm with solid phase extractions, however, this approach may be problematic for cleaning products
 - Require time consuming steps and special equipment (steam distillation apparatus or purge and trap system)
 - More applicable for surface and drinking water and raw materials
- These limitations with current EPA analytical methods suggest there will be analytical challenges with more complex product matrices
- ACI and its members are partnering to advance and make available an aligned, robust and accurate quantitative method for 1,4-Dioxane in consumer products



Further Method Considerations

- Recent publications with personal care and cleaning products reference the use of 1,4-dioxane-d₈ as an internal standard:
 - Zhou, W. **2019** The Determination of 1,4-Dioxane in Cosmetic Products by Gas Chromatography with Tandem Mass Spectrometry. *Journal of Chromatography A* 460400 (FDA paper)
 - Shin, H.; Lim, H. **2011** Determination of 1,4-Dioxane in Water by Isotopic Dilution Headspace GC–MS. *Chromatographia*, 1233–1236
 - Sun, M.; Lopez-Velandia, C.; Knappe, D. **2016** Determination of 1,4-Dioxane in the Cape Fear River Watershed by Heated Purge-and-Trap Preconcentration and Gas Chromatography–Mass Spectrometry. *Environ. Sci. Technol.* 2246–2254
- Use of deuterated internal standard approach provides a simple, robust method that could be used by contract labs, avoiding the need for special equipment or high-end capability in a formulation setting for testing of finished products
- Additional considerations needed for manufacturing facilities
- Regardless of end-user, standard method development, validation, round robin testing for aligned industry approach requires attention



Environmental Monitoring Data

- 1,4-Dioxane is reported to be present in WWTP effluents at mean concentrations of ~1 ppb in the US (Simonich et al., 2013), and ~1 ppb in CA influents (DTSC AAT proposal, 2019)
- CA tap water levels are reported to range from <0.05 to 5.83 ppb (EWG National Tap Water Database)
- **Probability is negligible that dioxane inputs from upstream WWTPs result in intake concentrations exceeding the USEPA drinking water advisory concentration of 0.35 µg/L, before any treatment of the water for drinking use (Simonich et al., 2013)**



Thank you for your attention!

Kathleen Stanton

Senior Director, Technical & Regulatory Affairs

kstanton@cleaninginstitute.org

